

ColumnCoat Application Guide

Materials Needed



Kit includes: One-2 quart bucket of concentrated bonder, One-2 gallon bucket of Column-coat dry mix and one empty 2 gallon bucket.



Additional tools needed: Drill and mixing bit, sand paper, a large brush, a smaller brush and a small roller.

Application Instructions



1
Lightly sand entire column, cap and base with 80-120 grit sandpaper



2
Mix bonder concentrate and water with drill until concentrate is completely diluted. The mixture yields 5 quarts.



3
Use the small roller column, cap and base with bonder.



4
Mix the ColumnCoat dry material with the remaining 2 quarts of diluted bonder from the small bucket.



5
Apply ColumnCoat. Texture is created with vertical or horizontal brush strokes.